

ZERO WASTE WARDROBE


LOOSE T-SHIRT HALF PATTERN - SMALLER VERSION


A4-PRINT

Printing: open the pdf file and select print. Go to the printing settings and select *Scale* and set it to 100%. The area of the first pattern page is 18cm X 27cm. You can test print the first pattern page (page 2) and measure the area between the dotted lines to make sure it is the correct size. After printing assemble the pieces according to the picture below.










T	:
	D 1
	B1
1	:
1	:
1	
	:
1	
1	;
	:
	:
	•
	:
1	
	:
1	
	:
	:
1	:
	:
1	:
	:
	•
	:
	:
	:
	•
	:
	:
	:
	:
	:
	•
L	





C2

C3

